


Servicing ONYX Counter Top Coolers

How to remove the top from the cooler:



Step 1:

- Remove two screws attaching front panel



Step 4:

- Lift off the top
- Note: Part is hooked in two places at the front



Step 2:

- Slide panel upwards and remove



You now have full access to the top of the cooler



Step 3:

- Remove two screws from rear of top cover