

Image number	Part number	Part description		
1	026551-002	12000 Bubbler Valve		
2	8983	Bubbler Valve Gasket		
3	9281	Friction Washer		
4	026655-002	Drain Screw		
5	26416	Condenser Shroud		
6	028965-005	Тор		
7	026630-005	Top Screw		
8	028706-001	Gasket (Under Top)		
9	18050	Waste Gasket		
10	026067-001	Precooler or Waste Assembly		
11	028742-001	Insulated Cooling Tank Assembly		
12	028660-001	Cooling Tank Insulation (RH)		
13	028661-001	Cooling Tank Insulation (LH)		
14	18456	Utility Cover - Painted		
15	18480	Utility Cover - Stainless Steel		
16	027040-007	Cold Control		
17	19743	Condenser		
18	17978	Relay		
19	17977	Overload		
20	018379-002	Base		
21	026540-005	Service Cord		
22	027256-002	Compressor (Includes Items 28 & 29)		
23	22977	Fan Blade		
24	027354-009	Fan Motor		
25	17557	Fan Motor Bracket		
26	019403-001	Side Panel - Painted		
27	019403-002	Side Panel - Stainless Steel		
28	018385-001	Front Panel - Painted		
29	018385-003	Front Panel - Stainless Steel		
30	18384	Rear Panel - Painted		
31	18479	Rear Panel - Stainless Steel		
32	026110-001	Shelf Assembly		
33	028701-002	Bubbler Spud		